


WiFi-2 Module Quick Installation Guide




LED indicator status description			
Blue	Blinking	Blinks blue slowly 5s on, 5s off	Module connected to server
		Blinks blue quickly, 0.5s on, 0.5s off	Inverter/ module is upgrading
	Off	Not connected to server	

Table 1 LED indicator status description

1. Installation & connection

Turn the module hexagon nut position to a horizontal position.



Insert the module into the inverter USB interface and fasten the hexagon nut in clockwise direction.

2. Installer Configuration

2.1 Download eSolar O&M APP

For iOS system, search “eSolar O&M” in App Store to download. For Android system, search “eSolar O&M” in Google Play to download.

2.2 WiFi-2 module connection

After installation of the module, power on the inverter. Wait for 2 minutes, if the module signal light is blue and blinking (refer to Table 1), it indicates that the module is working normally and sending data to server. If the station is built, the inverter information can be viewed in APP or website.

2.3 Bluetooth connection

- ① Turn on mobile phone Bluetooth connection.
- ② Sign in eSolar O&M APP → Select “My” → Select “Remote Configuration” → Select “Bluetooth” → “Next” → Search devices → Select the Bluetooth name of the WiFi module (such as BlueLink:00013) → Select a Wi-Fi and enter Wi-Fi password → Save



Fig 2.1 Bluetooth connection



Fig 2.2 Selecting WiFi module




Fig 2.3 Process of connecting module and router

3. Initial Setting

3.1 Grid compliance setting

Select the country, grid code and inverter time according to your local regulation.




Fig 3.1 Grid compliance setting

3.2 Working mode setting

Select the applicable working mode, the default mode is self-consumption mode.

Self-consumption mode

Electricity generated by PV panels will be supply to house loads first and store the surplus energy within the battery. Any excess is then exported to grid as feed-in.




Fig 3.2 Self-consumption mode

Time-of-use mode setting

Users can opt to charge the battery when the electricity price is low and discharge battery when the price is high.

Time-of-use Mode: Set battery charge/discharge hours manually.



Fig 3.3 Time-of-use mode

Backup mode setting

The battery will reserve a certain percentage of its electricity for few emergency backup loads to counter a blackout event. So that to avoid power interruption to essential loads.

Back-up Mode: Battery will be fully charged and will not discharge until there is a blackout



Fig 3.4 Back-up mode

3.3 Battery brand setting

Select the battery type according to your battery specification.



Fig 3.5 Battery brand setting

3.4 Measuring device setting

Meter is an optional measuring device. Select the measuring device according to your installation.



Fig 3.6 Measuring device setting

3.5 Zero export setting

Zero export function requires a meter installation. Zero export off: all inverter output power will be exported to the grid.

Zero export on: no or partial of inverter output power will be exported to the grid.

Percentage: the maximum inverter output power will be exported to the grid, e.g. set the export power to 80%, maximum 80% of the inverter output power can be exported to grid.




Fig 3.7 Zero export setting